

one cool inverter.



GT Series Solar Inverter Installation Manual v1.4

1.5kWGT(E) / 2kWGT(E) / 3kWGT(E)

About EnaSolar

EnaSolar Limited ("EnaSolar") is a division of Enatel Limited ("Enatel"), based in Christchurch, New Zealand. EnaSolar designs, builds, and supplies efficient, cost effective, sustainable and upgradeable solar inverters to the global market.

Trademarks

EnaSolar and the EnaSolar 'e' are both registered trademarks.

Notice of Copyright

Copyright © 2011 EnaSolar. No part of this document may be reproduced in any form or disclosed to third parties without the express written consent of EnaSolar Ltd. 66 Treffers Road, Christchurch 8042, New Zealand.

EnaSolar reserves the right to revise this document and to periodically make changes to the content hereof without obligation or organization of such revisions and changes, unless required to do so by prior arrangement.

Exclusion for Documentation

Unless specifically agreed to in writing, EnaSolar makes no warranty as to the accuracy, sufficiency, or suitability of any technical or other information provided in its manuals or other documentation. EnaSolar assumes no responsibility or liability for losses, damages, costs or expenses, whether special, direct, indirect, consequential or incidental, which might arise out of the use of such information. The use of any such information will be entirely at the user's risk. Steps have been taken to maintain the accuracy of translation of this manual into other languages other than English but there is no guarantee as to the correctness of such translations.

Date/Version

May 2011 v1.4

Applicable for products

1.5kWGT-AUNZ/UK	1.5kWGT-AUNZE/UKE
2kWGT-AUNZ/UK	2kWGTE-AUNZE/UKE
3kWGT-AUNZ/UK	3kWGTE-AUNZE/UKE

Contact Information

Phone: +64-3-366 4550
Fax: +64-3-366 0884
Email: support@enasolar.net
Web: www.enasolar.net

About This Manual

PURPOSE AND AUDIENCE

The purpose of this installation manual is to explain the procedures for installing and troubleshooting the EnaSolar GT Series Solar Inverter.

This manual is intended for qualified electrical installers. The Solar Inverter must only be installed by trained specialists.

Please read the installation manual thoroughly before installing the device and keep it safe for future reference.

SYMBOLS USED

Throughout the installation manual we use certain symbols. Here is what they mean:



WARNING

Warnings identify conditions that could result in personal injury or loss of life.



CAUTION

Cautions identify conditions or practices that could result in damage to the unit or other equipment.

IMPORTANT NOTICE TO THE INSTALLER

This manual must remain in the possession of the end user customer.

Once the installation has been completed the relevant data must be filled in the rear section of this manual. This data may be used for the customers' reference and to aid in any technical assistance.

WARRANTY REGISTRATION

To validate the warranty for a newly installed inverter, the registration must be carried out within 1 week of installation.

This form is to be filled out either on the EnaSolar website at:
www.enasolar.net/warranty

Or on the EnaSolar reporting software platform "Online" at:
<http://partner.enasolar.net>

Contents

About This Manual	3
Purpose and Audience	3
Symbols Used	3
Important Notice to the Installer	3
Warranty Registration	3
Safety Instructions	6
1. Introduction	7
About the EnaSolar GT Series Solar Inverter	7
Unit Description	7
Understanding the Part Number	8
Unpacking the Inverter	9
2. Installation	11
Installation Options	11
Before You Begin	11
Preparation	12
Location Requirements	12
Wi-Fi Networking Requirements	13
Installing the Wall mounting box	13
3. Wiring	15
Wiring Compartment	16
Earthing of Solar Modules	18
Additional Wall Mount Box Information	22
Inverter Module	23
4. Configuration	26
Network Setup	26
Installing the Installer Utility	26
Information Reporting	27
Using the Solar Installation Utility	27
General	28
Wireless Network Setup	29
Ethernet Network Setup	29
Test the customers Webpage	30
5. Using the System	32
Commissioning the System	32
Stopping the System	32
Navigating the front panel	33
6. Advanced Settings	35
Advanced Network Setup	35
Grid connect Settings	35
Time and date	36
Other	37
Information	38
Logs	38
Inverter Settings Web Page	40
Adhoc network	43
Lost or Forgotten Password / Password Reset	43
7. Troubleshooting	44
Installer Serviceable components	44
Network Troubleshooting	45
General Troubleshooting	46
8. Maintenance	47
Routine Maintenance Tasks	47

9. Technical Specification	48
Warranty	49
Warranty Registration	49
Glossary	49
Installation Data	50

Table of Figures

Figure 1 Installed Inverter	8
Figure 2 Unscrewing Display Module	9
Figure 3 Lifting Display Module	9
Figure 4 Removing Connectors	9
Figure 5 Disconnecting Inverter Plugs	10
Figure 6 Removing Inverter Module	10
Figure 7 Inverter Parts	11
Figure 8 Wall Mounting Box	13
Figure 9 Wall Mounting Box Fixed to the Wall	14
Figure 10 Wiring Compartment	16
Figure 11 PV Wire Connections	17
Figure 12 PV Connection to Earth Bar	18
Figure 13 Isolated Earth System	19
Figure 14 Positive Earth Connection	20
Figure 15 Negative Earth Connection	20
Figure 16 AC wiring connections	21
Figure 17 Multiple Unit Connections	22
Figure 18 Connecting the Inverter Module	23
Figure 19 Display Module (Wi-Fi) with Connections	24
Figure 20 Display Module (Ethernet) with Connections	24
Figure 21 General Setup Settings	28
Figure 22 Wireless Network Setup Settings	30
Figure 23 Customer's Internal Webpage	31
Figure 24 Display Home page	33
Figure 25 Display Totals page	33
Figure 26 Display Voltages page	34
Figure 27 Display Network page	34
Figure 28 Advanced Network Settings	35
Figure 29 Grid Connect Settings	36
Figure 30 Time and Date Setup Settings	37
Figure 31 Other Settings	37
Figure 32 Inverter Information	38
Figure 33 Daily log	39
Figure 34 Five minute log	39
Figure 35 Event log	40
Figure 36 Wireless Settings -Webpage	41
Figure 37 Network Settings -Webpage	41
Figure 38 Time & Date Settings -Webpage	42
Figure 39 Versions -Webpage	42
Figure 40 Installer Serviceable Components	44

Safety Instructions

This manual contains important safety and operating instructions. Keep it safe for future reference.

Before installing and using the inverter module, read all the instructions carefully.



WARNING

The following warnings identify practices that could result in personal injury or death.

When the device is in use it can become quite hot (up to 70° C in normal operation, depending on the ambient temperature). Do not touch the inverter while it is being operated or you may get burned.

Do not cover or obstruct the inverter, because it could overheat and become a fire hazard.

Make sure that the wiring is kept in good condition and is the correct size and type for its purpose.

Unless you are a qualified electrician, you must not open the inverter or attempt any type of repair or modification to the wiring. There may still be a high residual voltage within the inverter itself even if you have switched off the power source.

Never attempt to remove, repair or modify the inverter until the AC and DC power has been disconnected.



CAUTION

The following cautions identify conditions or practices that could result in damage to the unit or other equipment.

When installing the inverter make sure you follow the recommended clearances and location instructions. Do not install it in a location that does not have ventilation as this could lead to overheating and damage to the unit or significantly reduce its life or reduce power output.

Do not open the display module or the inverter module. They contain no user-serviceable parts.

1. Introduction

Chapter 1, Introduction, describes the features and functions of the EnaSolar GT Series Solar Inverter.

ABOUT THE ENASOLAR GT SERIES SOLAR INVERTER

The EnaSolar GT Series Solar Inverter is designed to convert solar energy to AC (mains) power, which can be used to power appliances in a home or business.

The EnaSolar GT Series Solar Inverter features:

- DC and AC isolating switches
- low operating voltage range, starting at 120V allowing you to install with a minimal panel array
- light weight inverter – 15kg in the 3kW unit
- built in Wi-Fi and stats package as standard, optional Ethernet version available
- 5 year warranty
- easy upgrade path to larger units, changing only the main module and re-using the back mount, control panel and all wiring.
- front mounted heat sink allows more airflow, easy care and cleaning
- an efficient design

UNIT DESCRIPTION

The EnaSolar GT Series Solar Inverter are made up of several components:

- a wall mounting box containing the wiring compartment
- a removable display module containing an LCD panel and Wi-Fi (Optional Ethernet)
- a removable inverter module containing the power electronics and heat sink
- a wireless antenna (not included with Ethernet version)



Figure 1 Installed Inverter

Dimensions

Case width	330mm
Case height (including switch handles)	550mm
Case depth	140mm
Total weight	15kg (for the 3kWGT unit)

UNDERSTANDING THE PART NUMBER

The Part Number of the EnaSolar GT Series Inverters can be broken down to for better understanding.

Taking for example the 1.5kWGT-AUNZE

1.5kW - the nominal output power of the inverter

GT - stands for Grid Tied

E - This identifies that the inverter is fitted with the Ethernet version of display. There are 2x versions of display interface: Ethernet and Wi-Fi. Wi-Fi is standard and if fitted there will be no E in the part number. I.e. 1.5kWGT-AUNZ

-AUNZ – This is the country identifier which has the specific parameters for the grid connect settings for that country. AUNZ (Australia/New Zealand) uses the same settings as they are both governed by the AS4777 regulations. For the -UK (United Kingdom) the settings are governed by the G83/1-1 regulations.

UNPACKING THE INVERTER

The GT Series Inverters comes partially assembled out of the box. This reduces the weight and cost of packaging/shipping. The packaging materials are recyclable to help reduce the materials going to landfill.

After removing the inverter from the box, undo the 4x screws, slide hands under the Inverter Module and lift to assist in removal of the Display Module.



Figure 2 Unscrewing Display Module



Figure 3 Lifting Display Module

Then carefully disconnect the 3x cables from the display PCB (ground tab, communications cable, Wi-Fi coaxial connector). *Note: When removing the coaxial connector do not pull on the cable. The Wi-Fi connector is not fitted for the Ethernet version.*




Figure 4 Removing Connectors

Set the Display Module aside.

Disconnect the 2x main inverter connectors by squeezing the side release tabs and carefully pulling out.



Figure 5 Disconnecting Inverter Plugs



Figure 6 Removing Inverter Module

Lift off the Inverter Module and then set aside

2. Installation

Chapter 2, Installation, contains information about how and where to install the EnaSolar GT Series Solar Inverter.

INSTALLATION OPTIONS

The EnaSolar GT Series Solar Inverter can be installed as a single inverter connected to a single PV array, or multiple PV arrays.

Multiple EnaSolar GT Series Solar Inverters can be installed side by side.

The EnaSolar GT Series Solar Inverter can be connected to a home network using Wi-Fi if one is available.

BEFORE YOU BEGIN

Unpack the box containing the EnaSolar GT Series Solar Inverter and make sure that you have all the required parts.



Figure 7 Inverter Parts

1) Wall mounting case	x1	4) Antenna	x1
2) Display module	x1	5) Conduit bungs	x2
3) Inverter module	x1	6) Mounting Hardware	x6

Note: If installing an Ethernet version display module (identified by an 'E' in the part number) there will be no antenna included.

Eliminate the chance of dissimilar metal corrosion by using the supplied mounting hardware.

If you are missing any of the inverter parts that you need for the installation, please contact your EnaSolar representative.

PREPARATION

Obtain the required network settings from the site owner (see the Network Setup section for further information).

Check that the panel configuration (voltage and current) is suitable for the inverter.

Have the latest version of Installation software loaded onto the notebook/PC that will be used to configure the inverter. Requires a minimum OS of windows XP or later. A USB to mini USB cable is required to connect from the notebook/PC to the inverter display module.

LOCATION REQUIREMENTS

The EnaSolar GT Series Solar Inverter can be installed indoors or outdoors. It must be installed somewhere with a free flow of air, where the ambient temperature is between -25°C and +50°C. It must be installed in a location that is out of direct sunlight during peak power times when the sun is at its hottest, as the sun's heat may interfere with the cooling abilities of the inverter module.

Our standard warranty terms can be found on our website. However the warranty may be compromised if the inverter is not installed in strict accordance with the installation guidelines contained in this installation manual. The minimum requirements for airflow around the heat sink are a major factor contributing to efficient cooling of the inverter and as a result the inverter should never be installed where these minimum space requirements are not met.

The inverter must be mounted vertically, with the wiring box at the bottom, on a wall or other flat surface, with at least 100cm clearance between the bottom of the unit and the ground, at least 40cm clearance between the top of the unit and any other surface and 7cm between any surface and the side of the inverter.

Do not mount inverters above each other or another source of hot air.

Do not install the inverter anywhere that it is likely to accumulate debris such as tree leaves or large amounts of dust.

Do not mount the inverter in a cupboard or an enclosed space. This may cause the inverter to overheat and potentially cause damage.

SURFACES FOR INSTALLATION

The wall mounting box can be attached to a vertical surface such as plaster board, wood siding, concrete wall, or pole assembly. Make sure the mounting surface is flat and can support the weight of the inverter (14kg) before you begin. If you are installing onto plaster board, use supporting material such as plywood or secure the fasteners to supporting wall studs. The inverter must not be installed directly on galvanised steel, for corrosion reasons.

WI-FI NETWORKING REQUIREMENTS

In order to make use of the wireless capabilities of the inverter unit, the homeowner must provide wireless networking capabilities. The wireless router must be located close enough to the inverter to have a minimum of 30% signal strength at the inverter location to maintain connection. (See the section on Wi-Fi range considerations on page 22 for more info)

The network security settings need to be known. The inverter is compatible with both WPA and WEP.

A list of known compatible wireless routers is available on the dealers section of the EnaSolar website.

INSTALLING THE WALL MOUNTING BOX

The metal wall mounting box comes with six pre-drilled 8mm screw holes for attaching it to the wall, as well as eight conduit holes for the electrical cables.



Figure 8 Wall Mounting Box

SUGGESTED INSTALLATION METHOD

1. Using the wall mounting box as a template, mark the required screw locations.
2. Set aside the wall mounting box and drill the marked screw hole locations. A minimum of four screws are required to fix the wall mounting box to the wall.
3. Using the supplied mounting hardware, fit the wall mounting box and insert screws through the drilled holes so that the box is held firmly in place. Ensure that you use the supplied fasteners that are capable of holding the unit securely.
4. Inspect the installation for any potential water leaks. Seal using an appropriate silicone sealant.

Note: If the inverter is incorrectly installed, this will void the warranty. Please see our warranty terms and conditions on our website.



Figure 9 Wall Mounting Box Fixed to the Wall

3. Wiring

Chapter 3, Wiring, contains instructions on how to correctly wire the EnaSolar GT Series Solar Inverter to the solar array and to the AC power.

Only solar trained electricians or other suitably qualified technicians should install this product.

WIRING REQUIREMENTS

Wire sizes must be coordinated with the array maximum short circuit current and the AC breaker sizes used. All wiring must be in accordance with applicable codes.

Wiring in Australia and New Zealand must meet AS/NZS3100 and AS4777 standards. AS4777 requires that the inverter feeds into a separate breaker on the AC distribution board. This breaker must be rated for bidirectional power flow. This standard also requires that specific signs and labels are attached to the distribution board and main AC distribution board. For further information consult the appropriate standards documentation.

Wire size for the AC and DC is critical. Undersized wiring can lead to significant power losses and a reduction in system efficiency.

- The maximum size for the DC cable is 16mm² or 6AWG (solid or stranded copper wire only).
- The DC cable must be rated for the maximum open circuit voltage of the panels. 600V min is recommended.
- The maximum size for the AC cables is 16mm² or 6AWG (solid or stranded copper wire only).
- The earthing terminal wire range is 2.5 – 25mm² (4 – 14 AWG) copper or 4 – 25mm² (4 – 12 AWG) aluminium solid or stranded wire.
- We recommend that the DC wires are a minimum of 4mm² and that the AC wires are a minimum of 2.5mm² to reduce voltage drop.

**WARNING – Fire Hazard**

Using undersized wiring can result in a fire hazard.

WIRING COMPARTMENT




Figure 10 Wiring Compartment

CONNECTING THE DC WIRING



WARNING – Risk of Electric Shock

Before you begin connecting the electrical components, make sure that the AC and DC switches are both in the Off position and the inverter module is not in place.

Ensure the incoming DC cables are disconnected at the PV cells.

Ensure the AC Inverter feed breaker on the distribution board is in the Off position.

There are 2x empty bung positions at either side of the wall mounting box to route conduit for wire entry. Ensure all unused conduit entry points are fitted with the spare conduit bungs that are supplied. If required these may be transposed to a desired conduit entry hole. Fix a suitable length of electrical conduit to the case. Feed the cables from the solar array through this conduit and into the wall mounting box, identifying the positive and negative cables as you do so.

If there are 2 arrays of panels, ensure that both of the strings are identical, i.e. the same number of panels in each string.

Strip 9mm ($\frac{3}{8}$ inch) of insulation from the wire(s). Insert the appropriate cables into the DC terminals. There are two terminals for PV+ and PV-, which allow you to wire two strings of panels in parallel.




Figure 11 PV Wire Connections

We recommend that the +ve wire(s) from the solar array is either red, or has a red sleeve attached.

Cable tie the DC wires to the PCB using the slot provided on the PCB.

Tighten the DC terminals to 1.2 – 1.5 Nm torque (10.6 – 13.3 Lb-In).

Do not route the AC and DC cables together in the same conduit, these must be kept apart using separate conduit routing.

CONNECTING THE PV PANEL EARTH CONDUCTOR

The PV panel earthing conductor from the solar array should be connected to the inverter's earthing bar.

Pull the PV panel earthing cable to the right-hand side of the wall mounting box, strip the end 10mm of wire, insert into one of the termination holes of the earthing bar and tighten into place.




Figure 12 PV Connection to Earth Bar

Tighten the earthing terminals according to your wiring:

16 – 25mm (4–6 AWG) / 5 Nm torque / 45 Lb-In

10mm (8 AWG) / 4.5 Nm torque / 40 Lb-In

2.5 – 6mm (10–14 AWG) / 8 Nm torque / 35 Lb-In

EARTHING OF SOLAR MODULES

The EnaSolar inverter allows three different options for the earthing of the Solar Module DC Poles: Isolated, Negative earth or Positive earth.

Note: this section refers to earthing the positive or negative of the Solar DC supply. The Solar Module frames should always be connected to earth.

ISOLATED EARTH SYSTEM

In this option (which is the default), the positive or the negative from the solar modules are not connected to earth. On startup, the inverter will test the impedance from both the +ve and the –ve DC input, to ensure that there is $> 600\text{k}\Omega$ (+/-15%) between the DC inputs and earth. If the inverter detects a lower impedance, it will display an error “PV Earth Fault”, and the RED LED will be on. The inverter will then continue with the startup tests and run.

If the inverter is displaying this fault, then the fault should be located and resolved. If left unresolved and a second earth fault occurs, then an electrically unsafe situation and a fire hazard could result. See PV earth fault in the troubleshooting section.

Note that the inverter has internal impedances, so ensure that the DC Isolating Switch is OFF before making any impedance measurements for trouble shooting.

To configure the EnaSolar inverter as an Isolated Earth System:

- 1) Ensure that the inverter is turned off – both the DC and AC isolators must be in the “Off” position.
- 2) Move the jumper on the end of the yellow/orange wire and place on the “Isolated” tab. This is the default selection, so the jumper does not need to be moved if an isolated earth is required.
- 3) When using the installation utility to configure the inverter, ensure that the option “Isolated” is selected on the PV panel earth section of the Setup page.

Note: If the inverter earth is selected as “None” there will be no monitoring of the PV panel earth.




Figure 13 Isolated Earth System

NEGATIVE OR POSITIVE EARTH SYSTEM

Some panels (particularly thin film) require that the negative or positive be connected to earth. This connection is via the large “Earth Fault” fuse.

To configure the EnaSolar inverter as a negative or positive earth system:

- 1) Ensure that the inverter is turned off – both the DC and AC isolators must be in the “Off” position.
- 2) Move the jumper on the end of the yellow wire and place on the “negative earth” or “positive earth” tab.
- 3) When using the installation utility to configure the inverter, ensure that the corresponding option is selected on the PV panel earth section of the Setup page.



Figure 14 Positive Earth Connection



Figure 15 Negative Earth Connection

For safety reasons ensure that all earth reference tabs that are not in use have a terminating jumper installed over the bare terminals.

If an earth fault occurs on the panels that results in a greater than 1A of PV current flowing to earth, the Earth Fault Fuse will blow, disconnecting the fault current path. The inverter will detect the blown fuse, will display “Earth Fuse Fail”, and will shut down, as an electrically unsafe situation and a fire hazard could exist.

If the Earth Fault fuse is blown, see the PV Earth Fuse fail in the troubleshooting section.

CONNECTING THE AC WIRING



WARNING – Risk of Electric Shock

Make sure the DC and AC switches on the inverter unit are set to Off, and the breaker switch in the AC distribution is set to Off, before you begin connecting the wiring.

There are 2x empty bung positions at either side of the wall mounting box to route conduit for wire entry. Ensure all unused conduit entry points are fitted with the spare conduit bungs that are supplied. If required these may be transposed to a desired conduit entry hole. Fix a suitable length of electrical conduit to the case. Feed the cables from the AC power supply through this conduit and into the wall mounting box.

Strip 9mm ($\frac{3}{8}$ inch) of insulation from the wires. Connect the phase and neutral from the mains power cable to the AC terminals on the right-hand side of the wiring panel.

Tighten the AC terminals to 1.2 – 1.5 Nm torque (10.6 – 13.3 Lb-In).

Cable tie the AC wires to the PCB using the slot provided on the PCB.

Do not route the AC and DC cables together in the same conduit, these must be kept apart using separate conduit routing.




Figure 16 AC wiring connections

CONNECTING THE AC EARTHING CONNECTOR

Pull the AC earthing wire to the right-hand side of the wall mounting box. Remove 10mm of insulation from the wire. Insert into one of the termination holes of the earthing bar and tighten into place.

Tighten the earthing terminals according to your wiring:

16 – 25mm (4–6 AWG) / 5 Nm torque / 45 Lb-In

10mm (8 AWG) / 4.5 Nm torque / 40 Lb-In

2.5 – 6mm (10–14 AWG) / 8 Nm torque / 35 Lb-In

CONNECTING MULTIPLE UNITS

If multiple inverters are being used each inverter unit must be wired to its own PV array. You can position multiple inverter units side by side on the wall. Please note that you must not connect the same panels into more than one inverter. For the AC connection we suggest that each inverter be wired to a different AC phase for phase balancing.

Second or subsequent PV array cables can be fed through the first inverter unit (thread the cable through the upper left-hand conduit hole, through the first inverter unit, out through the upper right-hand conduit hole and into the second inverter unit). This lets you keep the wiring tidy while still having separate connections.

Earth each inverter through its AC cable.

If you are connecting more than one unit, complete the wiring for each unit before moving on to the next one.




Figure 17 Multiple Unit Connections

If there will be more than one PV array, label the positive and negative wire pairs appropriately (for example, PV1 POS, PV1 NEG, PV2 POS, PV2 NEG).

CONNECTING THE WIRELESS ANTENNA

Note: This is not applicable for Ethernet version of the Display Module

The Solar Inverter is able to communicate with a network using a wireless link. The wireless coaxial cable comes pre-connected to the wall mounting box.

Screw in the antenna to the bottom of the wall mounting box.

ADDITIONAL WALL MOUNT BOX INFORMATION

If fitting an Ethernet version of Display Module ensure to route the communication cable (cat5 or cat6 Ethernet cable) in separate conduit to ensure that there is no noise induced into the communications line.

Ensure that all cables are outdoor rated if the inverter is mounted outside.

When routing the Ethernet cable ensure that there is sufficient length to be able to connect to the display module when it is being suspended, to allow for ease of configuration.

The EnaSolar GT Series Solar Inverter can be installed in stages. You have the option of installing the wall mounting box, wiring and inverter module at separate times or all together at the same time. If you are **not** installing the inverter module at this point, you can make the wall mounting box waterproof by installing the service panel. The service cover is available from your EnaSolar distributor.

If you **are** installing the inverter module at this point you should continue to the next section, “Inverter Module.”

INVERTER MODULE

CONNECTING THE INVERTER MODULE

**WARNING – Risk of Electric Shock**

Before connecting the inverter module, make sure that the AC and DC switches are both in the Off position

Prior to installing the inverter module, ensure that the following items have been checked:

- Every possible ingress point of water and dust is sealed correctly to maintain the IP rating.
 - There are no loose items, wire strands or debris inside the wiring area.
 - The fixing hardware is not over-torqued to ensure that the inverter housing does not warp.
- If the inverter is not installed correctly then the warranty is void.

Connecting the inverter module:

Slot the inverter module into place at the top of the wall unit, making sure that no cables are caught or pinched between the two units.

Connect the 6-pin and 9-pin plugs to their respective sockets in the wiring compartment.




Figure 18 Connecting the Inverter Module

ATTACH THE DISPLAY MODULE (WI-FI)

To attach the display panel to the inverter unit, connect the earthing wire from the back of display panel to the earth bar in the wiring box and fasten securely. The display panel can then be suspended from this wire while you work. Connect the four-pin lead to the display board. Connect the coaxial cable from the wireless antenna to the display board. Leave the display module open so that you can continue with configuration.




Figure 19 Display Module (Wi-Fi) with Connections

ATTACH THE DISPLAY MODULE (ETHERNET)

As per the above Wi-Fi version attach the Ethernet Display Module by connecting the Earth cable and the 4 way communication cable.

Connect the Ethernet cable to Ethernet port on the Display Module.




Figure 20 Display Module (Ethernet) with Connections

TESTING THE DC AND AC VOLTAGE

1. Switch off and lock DC and AC inverter switches.
2. Check that the solar array plugs are correctly installed.
3. Re-connect the solar array and expose it to full sunlight which is intense enough to produce the required output voltage.
4. Measure the PV array open circuit DC voltage across the DC positive (+) and negative (-) terminals in the wall mounting box. This voltage must be greater than 150 volts DC and less than 600 volts DC.
5. Turn on the breaker at the AC distribution.
6. Using an AC voltmeter, measure the AC open circuit voltage, and make sure that the voltage is at approximately the nominal value.
7. Turn on the DC isolator and measure the DC voltage at the terminals, this should not have changed.



Potential damage to inverter

The open circuit DC voltage must be less than 600 volts DC at all times, to prevent damage to the inverter.

4. Configuration

Chapter 4, Configuration, contains instructions on how to configure the EnaSolar GT Series Solar Inverter for use.

Note: The DC isolation switch on the inverter distribution must be turned on at this point.

The inverter will require to be configured to:

- Set the Network (Wi-Fi/Ethernet) settings
- Change any grid access settings from the default
- Set the panel earth setting

Configure the inverter as required following the instructions in the Configuration section.

NETWORK SETUP

WI-FI RANGE CONSIDERATIONS

Before you begin configuration you should establish whether the homeowner's wireless network is within range. A laptop, PDA or mobile phone with Wi-Fi can be used at the proposed site of Installation to test the signal strength. The inverter should be installed as close as possible to the user's access point. Ideally the signal strength will be at least 30% for reliable operation.

The range of wireless networks varies depending on the installation due to obstacles, reflections, and interference. The typical maximum range between the inverter and the access point (when going through walls) is 20m.

Any obstacle in the signal path between the inverter and access point will decrease the radio signal. High humidity and moisture on walls will absorb the radio signal and decrease the range. Walls with metal in them and concrete walls will decrease the signal strength significantly.

The aerials on the inverter and the access point should always be vertical. These aerials should also be mounted above ground and away from metal objects. Larger directional antennas can be used on the access point, inverter or both, if an increase in signal strength between them is required. Installing a directional antenna may not always increase the signal strength as there are many variables that influence the range.

Wi-Fi range is also affected by interference from other devices such as microwave ovens, 2.4GHz cordless phones, Bluetooth devices, and other Wi-Fi devices. If there is another Wi-Fi access point within range of the user's access point, the access point can be configured to operate on a different channel. For example, if a neighbouring access point is on channel 6 then configure the user's access point to channel 1 or 11.

INSTALLING THE INSTALLER UTILITY

The inverter requires software which you must use to configure its settings when installing a new inverter. This software is available from the Partners section of the EnaSolar website. This should be installed on a PC running Windows XP or later and with an available USB port. A laptop with built-in Wi-Fi is preferred.

Ensure that you have the latest version of installation utility installed on the PC prior to installing the inverter. All required software and supporting material is available from the EnaSolar website.

Once the software has been downloaded, follow the prompts on the installation utility to install the installation utility. Open the utility. At this stage the USB driver will install automatically.

INFORMATION REPORTING

If an inverter is connected to a wireless access point, data from the 5 minute and event logs will be collated and sent on the hour to EnaSolar servers in order to provide detailed performance data for the EnaSolar reporting software.

This information is read-only from the servers and will have no security concerns for the customer. The data that is pushed from the inverter contains no site or personal information.

There will be a limited amount of bandwidth use to push this data to the servers (approximately 1Mb of data per month).

This feature may be disabled by selecting a check box in the Advanced Settings of the Installation Utility. By doing this there will be no information about the inverter's performance sent to EnaSolar and therefore, they will not be able to monitor if there are any anomalies with the installation.

USING THE SOLAR INSTALLATION UTILITY

To configure a new inverter, connect the PC to the inverter using a USB to mini USB cable. The mini USB port is on the back of the display panel.

Start the EnaSolar Installer Utility.

If an inverter is not connected to the PC then the utility will display an error message. If this happens, plug the inverter in to the PC and click the scan button at the bottom of the page.

On any page the "Refresh this Page" button can be used to update the contents of the page.

CONFIGURATION

To configure a new inverter there are only a few steps required, all of which are on the Setup tab in the contents table on the left side of the screen.

Under the Setup tab there are three pages that need to have information entered: General, Time and Date and Wireless Network.

Enter the required details for each of the following fields.

GENERAL

Inverter Name

- a. With consultation with the site owner, enter the desired name for the inverter. The name can have a maximum alphanumeric character length of 20. The default name of the inverter is blank. The customer can then change the inverter's name at any time in the Settings page of the web interface. This name is displayed on the inverter web page. If there is more than one inverter, set a different name in each inverter to identify each web page.

Solar Settings

- b. Set the "DC Installed Capacity" to the nominal rated maximum power of the installed panels. For example, if twelve 175W panels are installed, set the DC Installed Capacity to 2100W (12 x 175).

PV Panel Earth

- c. Some PV panels require either the positive or negative line from the panel to be referenced to earth. The default setting is an isolated earth. In this selection, the earth reference is half of the total PV array voltage. Select the required PV panel earth reference: Isolated, Positive earth or Negative earth.

Note: The PV panel mounting frame must always be earthed back to the inverter earth bar.

Date, Time and Time Zone

- d. Set the time in the inverter by using the "Set to PC Time" button. This will set the inverter date, time and time zone to the date and time on the installer's PC.

Solar Installation Utility V2.05 - Setup

enASOLAR

Setup | Advanced Settings | Information | Logs

General | Wireless Network

Inverter Name: EnaSolar Inverter

Solar Panel Capability
DC - Installed Capacity: 1500 Watts

PV Panel Earth Fuse
Earth Fuse: Disabled

Date, Time and Time Zone
Set to PC Settings

Next

Refresh this Page

Serial Port Interface
COM Port: COM8 Scan

English | Information

Figure 21 General Setup Settings


WIRELESS NETWORK SETUP

You will need the following information before you begin:

- Name of the customer's wireless network (SSID)
- Encryption key or passphrase if the customer's network is encrypted.
- Authentication type (open/closed) if WEP security is used.

SETUP PROCESS

1. Click the scan button on the wireless network page to setup and search for a wireless network. If any wireless networks are within range, a list of the available access points will be displayed.
2. Select the customer's wireless network from the list by double clicking on it, or by selecting it and pressing "Connect".
3. If the customer's wireless network is encrypted, enter the key or passphrase for the wireless network into the popup box and press "Connect". If the security type is WEP, choose the appropriate authentication type from the drop down menu. Note: If you don't know the authentication type, try leaving it as the default (Open). In most cases this will be correct.



4. The inverter will try to connect to the access point. Upon successful connection with the access point, and if DHCP is enabled, it will attempt to get an IP address.

Note 1: If any of the above fails - refer to the Network Troubleshooting section.

Note 2: More advanced settings can be found on the advanced settings page.

ETHERNET NETWORK SETUP

Route a length of cat 5 or cat 6 Ethernet cable (through a separate conduit) from the customer's router to the inverter's display panel. Upon connection, if DHCP is enabled (most routers have DHCP enabled by default) the DHCP server inside the router will allocate an IP address for the inverter.

If there are multiple inverters on the same network you must configure the domain names to ensure there is not a conflict. By changing the Domain names to a different name per inverter (the default is: Enasolar-GT) there will not be any conflicts with trying to load individual web pages when searching using the domain name.

NETWORK SETTINGS

The Domain Name is the name that a user can use to access the inverter's web server via a web browser on the LAN. If more than one inverter is installed this should be changed so that each inverter has a unique domain name. Up to 15 characters may be used and should not contain spaces. The default domain name is Enasolar-GT.

Using a computer enabled for the customer's Wi-Fi; check that the inverter web page can be displayed. Enter 'Enasolar-GT' into the address of the browser. If this doesn't work, go to trouble shooting.



Figure 22 Wireless Network Setup Settings

If for any reason, the inverter does not operate as required with regard to the Setup sections, further parameters may be changed in the Advanced Settings tab. See section 6, page 35.

TEST THE CUSTOMERS WEBPAGE

To verify that the Wi-Fi is configured to the customer's router correctly, test the customers interfacing (inverter's internal) webpage.

- 1) Gain access to the customer's computer connected to the local network.
- 2) Open up the web browser (Internet Explorer, Firefox, Safari etc.)
- 3) Type either the Domain Name or the IP address into the title bar.

The Domain Name was selected upon setup or default – Enasolar-GT. The IP address that is issued to the inverter by the router's DHCP server is able to be viewed on the Network page (4th page) on the front panel. Ensure that the prefix http:// is used when searching for the webpage.




Figure 23 Customer's Internal Webpage

This should bring up the inverter's internal webpage. If this doesn't work, go to troubleshooting, see page 45.

5. Using the System

Chapter 5, Using the System, contains instructions on how to start and stop the EnaSolar GT Series Solar Inverter and how to monitor the system in use.

COMMISSIONING THE SYSTEM

CLOSE THE WIRING BOX

To close the wiring box:

1. Remove the USB cable that was connected to configure the settings.
2. Place the cover on the wiring compartment, ensuring that no cables are pinched between the wall mounting box and the cover.
3. Tighten the two captive screws on the left-hand and right-hand side of the cover.

Front panel symbols:



Generating – green LED.



Fault – red LED.

1. Turn the DC switch (on the bottom left of the wall mounting box) to the 'On' position.
2. Turn the AC switch (on the bottom right of the wall mounting box) to the 'On' position.



WARNING – Risk of Electric Shock

Make sure that all AC and DC wiring is correct before starting the inverter.

The display panel should read "Inverter starting up". After a moment the inverter will attempt to connect to the grid and display the message "Connecting to the Grid in XXs" (XX – this time is determined by the regional regulations, for AUNZ – 60s, for UK – 180s). The time will count down to 0 and then the inverter will start generating if there is power available from the PV panels and the AC connection is within the grid connect setting.

The system will automatically synchronise with the grid, the front panel will revert to the power output page and will display the generating (green) LED.

STOPPING THE SYSTEM

1. Turn the DC switch (on the bottom left of the wall mounting box) to the 'Off' position to cut off the power coming from the solar unit.
2. Turn the AC switch (on the bottom right of the wall mounting box) to the 'Off' position.

The display panel should be blank. The system will stop generating; the red LED will flash (battery power).

NAVIGATING THE FRONT PANEL

The front panel display shows key information pages. To scroll through these pages, lightly tap the metal front panel, (not on the see through screen). The backlight from the display will illuminate.

HOME

This screen shows the current production, yesterday's total production and today's total production.



Figure 24 Display Home page

TOTALS

This screen shows the inverter's total production (in kWhs) and the total time the inverter has been generating.



Figure 25 Display Totals page

VOLTAGES

This screen shows the input and the output voltages of the inverter.



Figure 26 Display Voltages page

NETWORK

This screen shows the IP address to which the inverter is connected, as well as the Wi-Fi signal strength.




Figure 27 Display Network page

ADHOC

When connected as an Adhoc network, this screen will display the access key.

EVENTS

If an event or fault occurs, this page will be displayed prior to the home page. During low light (dawn and dusk) a Low DC message will be displayed for the first page.

6. Advanced Settings

ADVANCED NETWORK SETUP

The Network Connection Details section shows the current details for the inverter's network interface.

The Network Settings section allows the inverter network interface settings to be changed.

DHCP Enabled – Enable or disable DHCP (enabled by default).

If DHCP is disabled then the Default IP Address, Default Subnet Mask, Default Gateway, Default Primary DNS Server, and Default Secondary DNS Server will need to be set. The Gateway and DNS should usually be set to the address of the router or access point.

The Web Administrator Username and Password that are used to log into and gain access to the settings web pages can be changed using this screen, consult the customer for their preference.

The Wireless Settings section allows the wireless settings to be changed at a lower level than the automated process on the Wireless Network page. Changing the region and deselecting scan channels is not advised. The default region is ETSI with all scan channels selected. Click the Write button to apply these settings.



Figure 28 Advanced Network Settings

GRID CONNECT SETTINGS

The grid connect settings set the parameters for the AS4777 / G83/1-1 grid disconnect. The inverter will disconnect if the AC mains goes lower than the minimum AC volts or greater than the maximum AC volts. The inverter will also disconnect if the frequency is less than the minimum AC frequency or greater than the maximum AC frequency.

The minimum and maximum voltage and frequency limits can be changed but this should only be done after discussion with the relevant electricity distributor. Timeouts cannot be changed and are displayed for information only.

The grid reconnect time is the minimum amount of time for the inverter to wait before reconnecting to the grid following a disconnection. The voltage and frequency must be stable and within range throughout the specified time period before the inverter will reconnect. The minimum grid reconnect time is determined by the regulation standards for each country.

To be able to change any of the voltage and frequency values you must enter your Installer ID and select the 'Unlock' button. This ID will be issued by EnaSolar upon application at the EnaSolar website.



Figure 29 Grid Connect Settings

TIME AND DATE

These settings are used if the computer you are using to configure the inverter has a different time/time zone that that which the inverter is being installed in, for example in a different state across the same country.

Date/Time

- Set the time in the inverter by using the "Set to PC Time" button, which will set the inverter date and time to the date and time on the installer's PC.

Time Zone

- Set the time offset by using the "Set to PC Time" button, which will set the inverter time zone to the UTC time offset on the installer's PC.

**Figure 30 Time and Date Setup Settings**

OTHER

This section displays the other inverter information such as totals: Energy Total and Hours Total. Also in this section is the program for copying and restoring parameters from the display module.

**Figure 31 Other Settings**

INFORMATION

This section displays the inverter information such as current generating data: Output Voltage, Output Power and Input Voltage. Also in this section the specific inverter information is stored such as: Name, Serial Number, and hardware and firmware revisions.



Figure 32 Inverter Information

LOGS

To read all the log entries for a particular log, click the “Read All” button. If there are many logs it can take some time to read all of them. To read the 20 most recent logs, click the “Read Last 20” button. To delete all log entries in a log, click the “Delete Log” button. To save the displayed log list to disk, click the “Export” button.

The three logs contain the following information:

Daily Log: Logs the amount of power produced each day and the amount of time spent exporting power to the grid for that day.

5 Minute Log: Logs every 5 minutes the various powers, voltages, currents, temperatures, auxiliary inputs and the operating state of the inverter.

Event Log: Logs any events that occur and the time that they occur. These events help to diagnose potential faults. Blank lines mean that all events were cleared at that time.

The end user customer only has access to the Daily log. The 5 min and event logs are intended for use by installers and EnaSolar personnel for diagnostic purposes.




Figure 33 Daily log




Figure 34 Five minute log



Figure 35 Event log

INVERTER SETTINGS WEB PAGE

These are an alternative to using EnaSolar software. These settings are available for user adjustment via the internal web page.

Once the inverter has been paired with the customers LAN/WLAN router using the Installation Utility, settings may be changed using the customers interface (internal web page).

The settings web page allows user access to network and time settings. The settings web page can be accessed from the main index page by following the “Settings” link from the main web page.

The settings page can also be accessed via Adhoc mode. See page 43 for details. Enter the web administrator user name and password when prompted. The default username is “Admin” and password “Admin1”.

Note “Grid Connect” settings cannot be changed via the web page.

WIRELESS SETTINGS

The wireless setting can be viewed and changed on the wireless settings page. To change the wireless settings enter the SSID, security mode, encryption type (if security mode is WEP) and the network key/passphrase. The region should be left to the default of ETSI in most cases. The wireless settings must match with those of the access point to which the inverter is connected. Click the Write button to save and apply the changes.




Figure 36 Wireless Settings -Webpage

NETWORK SETTINGS

The Network page allows the inverter's advanced network interface settings to be changed.




Figure 37 Network Settings -Webpage

DHCP Enabled – Enable or disable DHCP (enabled by default).

If DHCP is disabled then the Default IP Address, Default Subnet Mask, Default Gateway, Default Primary DNS Server, and Default Secondary DNS Server will need to be set. The Gateway and DNS should usually be set to the address of the router or access point.

The Domain Name is the name that a user can use to access the inverter's web server via a web browser on the LAN. If more than one inverter is installed this should be changed so that each inverter has a unique domain name. Up to 16 characters may be used and should not contain spaces. The default domain name is Enasolar-GT.

The Location is used to identify an inverter. It is displayed under the EnaSolar banner on the inverters web pages. By default the Inverter Name is blank.

The Web Administrator Username and Password are used to log into and gain access to the settings web pages.

Click “Write All” to save the settings to the inverter.

TIME SETTINGS

Date/Time

Set the time in the inverter by using the “Set to PC Time” button, which will set the inverter date and time to the date and time on the connected PC viewing this webpage.

Time Zone

Set the time offset by using the “Set to PC Time” button, which will set the inverter time zone to the UTC time offset on the user’s PC.




Figure 38 Time & Date Settings -Webpage

VERSIONS

This page is not editable but displays the serial number and version numbers of the inverter.




Figure 39 Versions -Webpage

HOME PAGE

The normal home page, current generation values, charts and settings can be accessed by following the home page link.

ADHOC NETWORK

If the inverter is unable to connect to a wireless access point it will create an Adhoc network. This allows the inverter's web page to be accessed wirelessly, so that the wireless network settings can be corrected. An Adhoc network is a computer-to-computer connection. Only one user at a time may connect to the inverter by this method. The Adhoc network can also be used by the customer to change inverter Wi-Fi encryption without requiring a serviceman using the installer utility, (this requires the wireless access point to be turned off).

Adhoc Default Settings:

IP Address:	10.10.5.5
Domain Name:	ENASOLAR-GT
Network SSID:	ENASOLAR-GT-0000000000 (10 digit serial number)
Security Mode:	WEP with Open Authentication
Network Password:	Displayed on front panel network screen (4 th page).
User Name:	Admin
Password:	Admin1

How to connect:

1. Using a PC disconnect from any wireless networks and scan for networks. Connect to the network that has the domain name of the inverter plus the serial number of the inverter appended to it. The default domain name is Enasolar-GT.
2. Enter the WEP Key for the Adhoc network when prompted.
3. In a web browser type the IP address (10.10.5.5) into the address bar.
4. When prompted for a user name and password enter these and click ok. The default user name is "Admin" and password "Admin1".

Disconnect from the Adhoc network when you are finished using it.

LOST OR FORGOTTEN PASSWORD / PASSWORD RESET

Turn off the access point to which the inverter is connected, so that an Adhoc network is created.

Follow the instructions in the Adhoc section on how to connect to an Adhoc network. When prompted for a user name and password, enter the default user name ("Admin") and password ("Admin1").

Go to the network settings web page and change the Web Administrator Username and Web Administrator Password to the customers preferred choice, and click "Write All" to save the settings.

7. Troubleshooting

Chapter 7, Troubleshooting, contains instructions on how to resolve problems with the EnaSolar GT Series Solar Inverter after installation.

The inverter will store all faults and events that occur.

At extremely high or low temperatures the display module may not function correctly.

INSTALLER SERVICEABLE COMPONENTS

1. MOV (-ve to +ve).
2. MOV (-ve to earth).
3. PV Earth Fault Fuse.
4. MOV (AC protection).

Each of the parts will be available from your EnaSolar representative and can only be replaced by a trained solar technician.




Figure 40 Installer Serviceable Components

REMOVING THE DISPLAY MODULE



WARNING – Risk of Electric Shock

Take care when removing the display module. There is live DC and AC power on the wiring terminals.

To remove the display module (which also acts as the wiring compartment cover):

1. Turn the AC and DC switches to the 'Off' position.
2. Remove the two captive screws on the left-hand and right-hand side of the cover, and carefully remove the display module out for access to the connectors.
3. Disconnect the 4 way connector, the wireless coaxial connector and the earth connector.
4. Carefully set aside the display module.

REPLACING THE DISPLAY MODULE

**WARNING – Risk of Electric Shock**

Take care when replacing the display module. There is live DC and AC power on the wiring terminals.

To replace the display module (which also acts as the wiring compartment cover):

1. Ensure that the AC and DC switches are in the 'Off' position.
2. Connect the 4 way connector, the wireless coaxial connector and the earth connector.
3. Place the cover on the wiring compartment, ensuring that no cables are pinched between the wall mounting box and the cover.
4. Replace the two captive screws on the left-hand and right-hand side of the cover and tighten securely.

If a replacement front panel is required to be fitted, the historic data that has been saved on the older unit can be transferred by using the transfer function on the Installation Utility. This can be found within the "Advanced Settings" page under the tab labelled "Other".

NETWORK TROUBLESHOOTING

All issues

If the signal strength is less than 30%, move the access point closer to the inverter if possible and/or try a larger antenna on either the inverter or access point, or both.

Check the access point is configured in "mixed mode" with "b" compatibility enabled.

A repeater may need to be installed if the access point cannot be moved closer. Consult EnaSolar for further details.

Access Point Not Found

Check that the access point is switched on.

Check the aerial connections on the inverter and access point.

Move the access point and inverter closer together if possible.

Security Not Matched

Check that the wireless security settings match with the access point.

Failed to Join Network

Check that the wireless settings match with the access point.

Failed to Authenticate

Check that the WEP key and WEP authentication type or WPA passphrase match with the access point.

Failed to Associate

Check that the WEP key and WEP authentication type or WPA passphrase match with the access point.

Check that MAC filtering is not enabled on the access point. If it is disable it, or add the MAC address of the inverter to the allowed list.

Adhoc Connected

A user is connected to the inverter by the Adhoc connection.

Failed to get an IP Address

If there is no DHCP server on the network, disable DHCP and manually enter the default IP address, DNS IP and Gateway IP in the advanced settings page of the Solar Installation Utility.

If there is a DHCP server on the network, then the user's access point may be transmitting wireless broadcasts at the wrong rate. Change the base transmit rate of the access point to 2 Mb/s. Look at the documentation for the access point on how to do this. Otherwise set the inverter to have a static IP and manually enter the default IP address, DNS IP and gateway IP in the advanced settings page of the Solar Installation Utility.

Web page can't be accessed using the IP address

Check that the IP address has been entered correctly and that both the inverter and computer from which the web page is being accessed from are successfully connected to the same network.

Web page can't be accessed using the Domain Name as the address

Try to access the web page using the IP address displayed on the network page of the LCD screen. If the web page can be accessed through the IP address then the access point is transmitting broadcasts at the wrong rate. Change the base transmit rate of the access point to 2 Mb/s (refer to the documentation for the access point on how to do this).

GENERAL TROUBLESHOOTING

NO DC

- Check that the DC Isolator switch is on; check the PV array is in circuit and is fully exposed to sunlight.
- Check the polarity of the PV input, reverse polarity will display as 0V.

NO AC

- Check that the AC Isolator switch is on.
- Check that the AC circuit breaker is on at the switchboard.

PV Earth Fault

Isolated Earth – this means there is less than 600kΩ between the +ve or -ve PV input and earth. I.e. the cabling for the PV array has developed a fault from either the positive or negative input to ground.

This will display the message "PV Earth Fault" and will continue to operate.

Possible causes:

- Faulty cell in one of the PV modules.
- Cracked / Corroded / Damage PV module
- Chaffed or damaged wiring.
- Incorrect wiring or configuration.

This situation has a fault that needs to be address but will continue to operate as under an isolated earth installation, it is not necessarily an unsafe situation but has the potential to become a fire and safety risk should another fault occur.

To help diagnose where the problem lies, while the inverter is running, measure the following voltages:

Positive to Negative

Positive to Ground

Negative to Ground

By comparing these values, this will give an indication where the problem lies.

PV Earth Fuse

Positive or Negative Earth – If this alarm is generated, a current of greater than 1A is flowing to ground, blowing the earth fault fuse. Once the fault has been verified, the Earth Fuse will need to be replaced, see below for the procedure.

**WARNING – Risk of Electric Shock**

The PV Earth Fuse must only be replaced by a trained solar technician.

- Ensure that both the AC and DC isolator switches are turned off.
- De-energise both the AC (from the switchboard) and DC (PV array) feeds into the inverter.
- Gain access to the wiring compartment by removing the display module.
- Check if the Earth Fault Fuse is open and leave the fuse holder open.
- Inspect the PV array for any possible cause of the fault and remedy as required.
- Replace the fuse with – 1A, 600Vdc Littlefuse KLKD 1
- Refit the display module and reenergise the system.
- If the PV earth fault still exists, contact the EnaSolar Service department.

MOV Fail



WARNING – Risk of Electric Shock

Any of the MOV protection devices must only be replaced by a trained solar technician.

- Ensure that both the AC and DC isolator switches are turned off.
 - Gain access to the wiring compartment by removing the display module.
 - Inspect each of the MOV's fitted in the system:
 - 2x DC protection: negative – positive and negative – earth.
 - 1x AC protection: phase – neutral.
- Note: The MOV fail alarm will be generated when any of the 3x MOV's has failed.
- Replace the applicable MOV. These items are available from your EnaSolar distributor.
 - Refit the display module and reenergise the system.
 - If the MOV Fail alarm still exists, contact the EnaSolar Service department.

8. Maintenance

Chapter 8, Maintenance, covers common maintenance tasks that should be carried out for the EnaSolar GT Series Solar Inverter after installation.

ROUTINE MAINTENANCE TASKS

Keep the inverter heatsink clean and clear of cobwebs, dust, leaves, etc, by sweeping it with a broom or something similar on a regular basis.

Use a soft damp cloth to clean the outside of the inverter if required.

If the inverter is installed into a salty environment (near the sea), ensure that the inverter is regularly hosed down with a light spray.

9. Technical Specification

Chapter 9, Technical Specification, describes the technical specification of the EnaSolar GT Series Solar Inverter.

Input	1.5kW Model	2.0kW Model	3.0kW Model
Maximum Open Circuit Voltage (Voc):	500V DC	600V DC	600V DC
MPP Operating Voltage Range (Vmpp):	120-450V DC	120-450V DC	120-500V DC
DC Nominal Operating Voltage:	300V DC	350V DC	300V DC
Maximum Input Current (Impp):	11A	12A	15A
Maximum Usable Input Power (Pmax):	1640Wp	2200Wp	3200Wp
Maximum Allowable Input Power:	2250W	3000W	4500W
Reverse Polarity Protection:	Inherent crowbar diodes.	Inherent crowbar diodes.	Inherent crowbar diodes.
Isolation From AC Mains:	High frequency transformer.	High frequency transformer.	High frequency transformer.
Earthing:	Isolated, +ve earth, -ve earth selectable.	Isolated, +ve earth, -ve earth selectable.	Isolated, +ve earth, -ve earth selectable.
Output			
Nominal Output Voltage:	230V AC	230V AC	230V AC
Output Voltage Range:	202-259V AC	202-259V AC	202-259V AC
Max Output Current:	7.5A	10A	15A
Line Frequency:	50Hz	50Hz	50Hz
Total Harmonic Distortion:	<5% at full load, nominal output voltage.	<5% at full load, nominal output voltage.	<5% at full load, nominal output voltage.
Max Efficiency:	>95% TBC	>96%	>96.5%
Max Euro Efficiency:	>93% TBC	>94.5%	>94.5%
Nominal Output Power:	1500W	2000W	3000W
Maximum Output Power:	1600W	2100W	3100W
Power Factor:	>0.98	>0.98	>0.98
System	Inbuilt lightning surge protection. Integrated lockable DC and AC disconnect. Integrated wiring box with removable inverter module.		
Islanding Protection:	AS4777.3, G83/1-1	AS4777.3, G83/1-1	AS4777.3, G83/1-1
Night-time Consumption:	<1.2W	<1.2W	<1.2W
Operating Temperature Range:	-30°C to +50°C (full power), +70°C (derated)	-30°C to +50°C (full power), +70°C (derated)	-30°C to +50°C (at V AC nom), +70°C (derated)
Acoustic Noise:	<33dBa @ 1m.	<33dBa @ 1m.	<33dBa @ 1m.
Display:	4 line x 16 character. (no buttons)	4 line x 16 character. (no buttons)	4 line x 16 character. (no buttons)
Data Interface:	Wi-Fi IEEE 802.11 with web interface.	Wi-Fi IEEE 802.11 with web interface.	Wi-Fi IEEE 802.11 with web interface.
Environmental Rating:	IP55	IP55	IP55
Mechanical:	330mm x 550mm x 145mm. (excluding antenna) 14kg	330mm x 550mm x 145mm. (excluding antenna) 14kg	330mm x 550mm x 145mm. (excluding antenna) 15kg
1.5/2.0/3.0kW Standards			
EN61000-6-3:	"Emission standard for residential, commercial and light industrial environments", class B		
EN61000-6-1:	"Immunity for residential, commercial and light-industrial environments"		
EN61000-3-2:	"Limits for harmonic current emissions"		
EN61000-3-3:	"Limitations for voltage fluctuations and flicker"		
EN62233:	"Electromagnetic fields for household appliances"		
AS4777-2, AS4777-3:	"Grid connection of energy systems via inverters"		
G83/1-1:	"Recommendations for small scale embedded generators"		
AS/NZ3100:	"Electrical safety"		
BS50178:	"Electrical safety"		
C-Tick, CE:	Declarations		

Warranty

Our standard warranty terms and conditions are available on the EnaSolar website.

<http://www.enasolar.net/Products/EnaSolar-Limited---Inverter-Warranty>

In no event shall EnaSolar be responsible for indirect or consequential damages or lost profits even if EnaSolar has been advised of the possibility of such damages. EnaSolar Ltd's sole obligation to you shall be the repair or replacement of a non-conforming product.

Warranty Registration

To validate the warranty for a newly installed inverter, the registration must be carried out within 1 week of installation.

This form is to be filled out on the EnaSolar website at: www.enasolar.net/warranty

Alternatively the installation can be registered on "Online" at: <http://partner.enasolar.net> under an individual installer login.

Glossary

PV Array	Photovoltaic Array (solar panels)
Nm	Newton metre
Lb-In	Pounds-inches
PV	Photovoltaic
LCD	Liquid Crystal Display
LED	Light Emitting Diode
MOV	Metal Oxide Varistor – A transient protection device.
AC	Alternating Current
DC	Direct Current

INSTALLATION DATA

This section must be filled in by the installer.

Installers Details

Company Name	
Installers Name	
Contact Ph / email	

Solar Panel Data

Panel Manufacturer				
Model of Panel				
Panel Configuration	No. of strings		No. of panels in string	

Page intentionally blank.

Manufactured by: EnaSolar Limited
66 Treffers Road, Christchurch 8042, New Zealand
Tel +64-3-366 4550 | Fax +64-3-366 0884
www.enasolar.net

